

## SPIRIT WATER BASED PREMIUM SEAL

### Technical Data Sheet

#### **Product Description**

A water-based Green Star rated low VOC penetrating sealer that provides a natural-look finish with long life benefits. **Water Based Premium Seal** provides the very best protection from oil & waterborne staining.

Waterbased	Penetrating (impregnating) sealer	Can be used in wet areas (showers & water features)	Can be used on polished surfaces	Can be used internally or externally
YES	YES	YES	YES*	BOTH
Allows moisture vapour transmission	Repels Oil & Water	Alters appearance	Alters slip resistance	Can be used prior to grouting
YES	YES	NO	NO	YES*

\*Excess sealer may cause streaking and will need to be buffed off polished substrates.

#### **Where to Use**

Internal & external porous tile, stone & concrete surfaces.

- Natural stones such as travertine, limestone, marble, bluestone, sandstone, granite & slate
- Terracotta, terrazzo, concrete & clay pavers

#### **Expected Wear**

Weather conditions, location & harsh cleaning methods using high pressure cleaners, high-alkaline, acid or solvent-based cleaners will affect the long-term performance of the sealer and may even damage the substrate. Following the appropriate **Spirit Guide** relating to your substrate will ensure the very best protection.

#### **Available Sizes**

1L, 4L & 15L Drums.

## APPLICATION OF WATER BASED PREMIUM SEAL

**Before commencing sealing it is a requirement to test first before use.**

### Testing instructions

For new installations the test should be carried out on a spare piece of stone. For stone that has a lot of colour variation, it is advised to test on two different pieces, preferably one lighter and one darker. Put some painters tape down the middle of the test pieces. Using a dry absorbent white cloth, seal only one half to get an idea if there is any colour change, keeping in mind that penetrating sealers may slightly darken or lighten the stone. Follow the how to use guide below. Allow the sealed stone to cure for a minimum of 72 hours before testing the water and oil resistance.



Follow the how to use guide below. Allow the sealed stone to cure for a minimum of 72 hours before testing the water and oil resistance.

**Note:** The testing phase is extremely important as it allows you to determine if you are satisfied with the finished look. For existing areas, test in an inconspicuous area.

If you are unsure about any of the above contact Spirit Sealers before commencing.

### How to use

1. The surface to be sealed must be clean and completely dry before sealing is done.
2. Apply **Water Based Premium Seal** evenly with a microfibre applicator, garden pump sprayer or a dry absorbent white cloth.
3. To ensure total and even coverage, apply the first coat in a North/South direction and the second coat in an East/West direction.
4. Using a dry white cloth, remove any excess sealer that hasn't penetrated into the stone after 10-15 minutes.
5. Apply a second coat after approximately 30-45 minutes and again remove any excess sealer after 10-15 minutes.
6. If more coats are applied, be sure to remove the excess as outlined in step 4.
7. For vertical application, apply **Water Based Premium Seal** from the bottom up to prevent the sealer from leaving run marks down the wall.
8. Curing takes 24 hours, but the sealed area can see foot traffic after approximately 2 hours depending on the porosity of the stone and the weather conditions.
9. It is very important that no water (including rain) comes into contact with newly sealed surfaces for a minimum of 24 hours after sealing. It is advised to check weather conditions prior to sealing exposed outdoor areas.

### Precautions

1. **Water Based Premium Seal** should only be applied in temperatures between 10-25 degrees Celsius.
2. All surrounding areas that are not intended to be sealed must be protected from contact with the sealer. Cleaning solvents may be necessary to remove accidental application. If spraying, avoid doing so in windy conditions to control overspray.
3. Excess sealer can be buffed off using a clean white rag.
4. Appropriate gloves and goggles must be worn during application.

**Coverage** Depends on the porosity of the surface, temperature and method of application.

Approximate coverage rates per litre are as follows: **sandstone / concrete pavers:** 4-6m<sup>2</sup>, **limestone / marble / travertine / granite / terrazzo:** 8-10m<sup>2</sup>

Clean up tools after application with water

**CLEANER & SEALERS FOR THE TILING INDUSTRY**

